

FUEL FILTER

The fuel filter is incorporated in the fuel valve. Accumulation of dirt in the filter will restrict the flow of fuel and therefore, the fuel filter should be serviced periodically.

1. Drain the fuel from the fuel tank. Disconnect the fuel line.

WARNING


* *Gasoline is extremely flammable and is explosive under certain conditions. Perform this operation in a well ventilated area. Do not smoke or allow flames or sparks in the area.*

2. Remove the fuel valve (1) by loosening the mounting bolt and remove the fuel filter (3). Wash it in clean non-flammable or high flash point solvent.

WARNING

* *Never use gasoline or low flash point solvents for cleaning the fuel filter. A fire or explosion could result.*

3. Make sure the O-ring (2) is in place. Reinstall the fuel filter and fuel valve in the reverse order of removal and turn the fuel valve ON. Check for leaks.
4. Check the fuel line for deterioration, damage or leakage. Replace if necessary.



(1) Fuel valve

(3) Fuel filter

(2) O-ring