


ESSENTIAL INDIVIDUAL COMPONENTS

Ignition Switch

The ignition switch (1) is on the right side below the steering stem.



(1) Ignition switch

Key Position	Function	Key Removal
LOCK (steering lock)	Steering is locked. Engine and lights cannot be operated.	Key can be removed
OFF	Engine and lights cannot be operated.	Key can be removed
(ON)	Engine and lights can be operated.	Key cannot be removed