


## Rear Turn Signal Bulb

The right and left turn signal bulbs replacement can be done in the same way.

1. Remove the rear turn signal lens (1) by removing the screw (2).
2. Slightly press the bulb (3) and turn it counterclockwise.
3. Install a new bulb in the reverse order of removal.
  - Use only the amber bulb.



- (1) Turn signal lens  
(2) Screw  
(3) Bulb