

Shifting Gears *(Continued)*

Neutral (N): Neutral is selected automatically when you turn the ignition switch to on.

If neutral is not selected when you turn the ignition switch to on:

- ▶ Turn the ignition off and on again.
- ▶ If neutral is still not selected after turning the engine off then on again. **➡ P.97**
You may hear (click) noises when the transmission shifts to Neutral (N). This is normal.

When you can change between N and D

- ▶ Motorcycle is stopped and the engine is idling.
- ▶ Throttle is completely off. It is not possible to change from Neutral to D mode while the throttle is applied.
- ▶ You cannot change between N and D mode while the wheels are rotating.
- ▶ Side stand is raised.

NOTICE

- To prevent clutch damage, do not use the throttle to keep the motorcycle stopped uphill.