

Rear Brake Lock

Be sure the rear brake is applied while starting and warming up the engine.

To apply the rear brake lock

Squeeze the rear brake lever and set the rear brake lock lever.

- ▶ The rear brake lock will not function if the rear brake is not adjusted properly.

➔ P.68

To release the rear brake lock

Squeeze the rear brake lever.

- ▶ Before riding, make sure that the rear brake lock is fully released so there is no drag on the rear wheel.

