

Tyre Repair/Replacement:

See your authorized Honda Dealer.

⚠ WARNING

- * **The use of tyres other than those listed on the tyre information label may adversely affect handling.**
 - * **Do not install tube-type tyres on tubeless rims. The heads may not seat and the tyres could slip on the rims, causing tyre deflation that may result in a loss of vehicle control.**
 - * **Do not install a tube inside a tubeless tyre. Excessive heat build-up may cause the tube to burst resulting in rapid tyre deflation that may result in a loss of vehicle control.**
 - * **Proper wheel balance is necessary for safe, stable handling of the motorcycle. Do not remove or change any wheel balance weights. When wheel balancing is required, see your authorized Honda dealer. Wheel balancing is required after tyre repair or replacement.**
- * **To avoid possible repair failure and tyre deflation that may result in a loss of vehicle control, do not exceed 80 km/h (50 mph) for the first 24 hours, or 130 km/h (80 mph) at any time, after tyre repair.**
 - * **Replace the tyre if the sidewall is punctured or damaged. Sidewall flexing may cause repair failure and tyre deflation that may result in a loss of vehicle control.**