

////////////////////// TIRE RECOMMENDATION //

Correct inflation pressure will provide maximum stability, riding comfort and tire life. Be sure to follow the tire specification.

NOTE: Over or under inflation of the tires causes abnormal tread wear or other defects which may result in serious accidents. Riding with under-inflated tires will cause the tires to slip out of place in the rims, damaging the innertube valves.

From time to time check the tires for inflation pressure and correct it, if necessary.

| Cold tire pressure: psi (kg/cm ²) | |
|---|-----------------|
| Driver only | Front: 26 (1.8) |
| | Rear: 28 (2.0) |
| Driver and passenger | Front: 26 (1.8) |
| | Rear: 34 (2.4) |
| Tire size | Front: 2.75-21 |
| | Rear: 3.25-18 |