

Installation Notes:

- Reverse the removal procedure.
- Insert the axle through the wheel hub and left fork leg.
Make sure that the tang (5) on the fork leg is located in the slot (6) in the brake panel (7).
Tighten the front axle.
Front axle torque: 60–80 N·m (6.0–8.0 kg·m, 43–58 ft-lbs)
- Check the brake adjustment.
- Apply the brake several times and check for free wheel rotation when released.

WARNING: If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly.

