

3. Remove the screws (1) (Fig.4-5) and remove the air cleaner assembly (2) from the air cleaner housing.
4. Unscrew the clamp (3).
5. Remove the air cleaner (4) from the air cleaner body (5).




Fig. 4-5 (1) Screw
(2) Air cleaner assembly

(3) Clamp
(4) Air cleaner
(5) Air cleaner body