

Basic Operation & Riding

This section gives basic riding instructions, including how to start and stop your engine, and how to use the throttle and brakes. It also provides important information on riding with cargo.

To protect your new engine and enjoy optimum performance and service life, refer to Break-in Guidelines (page 244).

For information about carburetor adjustment for riding at high altitude, see page 245.

Safe Riding Precautions	91
Off-Road Use Only	91
Keeps Hands and Feet on Controls	92
Control Speed.....	93
Use Care on Unfamiliar or Rough Terrain.....	94
Do Not Perform Stunts.....	95
Starting & Stopping the Engine	96
Preparation	96
Starting Procedure	97
Flooded Engine	99
Stalled Engine	99
How to Stop the Engine	100
Using the Recoil Starter	101
Shifting Gears	102
Riding in Reverse.....	108

(cont'd)