

## **MAINTENANCE**

page

<b>72</b>	<b>MAINTENANCE</b>
72	THE IMPORTANCE OF MAINTENANCE
73	MAINTENANCE SAFETY
74	SAFETY PRECAUTIONS
75	MAINTENANCE SCHEDULE
78	TOOL KIT
79	SERIAL NUMBERS
80	COLOUR LABEL
81	ENGINE OIL
87	CRANKCASE BREATHER
88	SPARK PLUGS
92	THROTTLE OPERATION
93	IDLE SPEED
94	COOLANT
95	DRIVE CHAIN
101	DRIVE CHAIN SLIDER
102	FRONT AND REAR SUSPENSION INSPECTION
103	SIDE STAND
104	WHEEL REMOVAL
112	BRAKE PAD WEAR
113	BATTERY

page

115	FUSE REPLACEMENT
118	STOPLIGHT SWITCH ADJUSTMENT
119	BULB REPLACEMENT
<b>124</b>	<b>CLEANING</b>
<b>128</b>	<b>STORAGE GUIDE</b>
128	STORAGE
130	REMOVAL FROM STORAGE
<b>131</b>	<b>SPECIFICATIONS</b>
<b>135</b>	<b>CATALYTIC CONVERTERS</b> < Except U type >
<b>136</b>	<b>NOISE CONTROL SYSTEM</b> (AUSTRALIA ONLY)