



Spark Plug

2. Disconnect the spark plug cap.
3. Remove the spark plug with the multi-purpose wrench (1) provided with your motorcycle.
4. Inspect the spark plug electrodes for wear. The center electrode (2) should have square edges. The side electrode (3) should not be eroded. The insulator should not be cracked or chipped.
5. Check the spark plug gap (4), using a wire-type feeler gauge. If adjustment is necessary, bend the side electrode carefully. The gap should be:
0.024—0.028 in (0.60—0.70 mm)
Make sure the plug washer is in good condition.
If you have to install a new plug, first check the gap.
6. With the plug washer attached, thread the spark plug in by hand (to prevent cross-threading).



7. Tighten the spark plug:
 - about 1/8-1/4 turn after it seats (if the old plug is good).
 - about 1/2 turn after it seats (if installing a new plug).

NOTICE

Improperly tightened spark plugs can damage the engine. Too loose, you can burn a piston. Too tight, you can damage the threads.

