



Quick Reference

Initial Maintenance	about 100 miles (150 km) or one month.
Regular Maintenance	about every 600 miles (1,000 km) or six months.
Pre-ride Inspection	Check the following items each time before you ride (page 24): tires, spokes & rims, leaks, engine oil, fuel, drive chain, cables, nuts & bolts, spark plug and cap, throttle, brakes, clutch lever, headlight.
Fuel/Capacity	unleaded gasoline, pump octane number of 92 or higher tank: 2.51 US gal (9.5 ℓ) reserve: 0.40 US gal (1.5 ℓ)
Engine Oil	API Service Classification SG or higher except oils labeled as energy conserving on the circular API service label, SAE 20W-50, 10W-40 (when outside temperature is below 0°C, 32°F), JASO T 903 standard MA, Pro Honda GN4 or HP4 (without molybdenum additives) 4-stroke oil or equivalent
Maximum Weight Capacity	220 lbs (100 kg) rider only (no passenger or cargo) and any accessories
Tires	Front: 80/100-21M/C 51M Rear: 110/100-18M/C 64M
Tire Pressure (cold)	Front: 15 psi (100 kPa, 1.0 kgf/cm²) Rear: 15 psi (100 kPa, 1.0 kgf/cm²)
Spark Plug	DPR8Z (NGK) or X24GPR-U (DENSO)
Drive Chain	D.I.D. 520V8 or RK 520MOZ6

Quick Reference

