

Tires

Tires must be in good condition in order to ride your motorcycle safely.

Always keep the tire pressure within the specified range. Replace tires that are worn out.

WARNING

Worn out tires and wrong tire pressures may cause accidents and injuries.

Always adhere to specified tire pressure and replace worn out tires.

<Checking air pressure>

Check the tire shape when the wheels are in contact with the ground. If the shape of the tire looks abnormal, check the tire pressure when cold with a tire air pressure tester.

