


## Adjusting the Clutch Lever Freeplay

CRF1000A

### Upper Adjustment

Attempt adjustment with the upper clutch cable adjuster first.

1. Loosen the upper lock nut.
2. Turn the upper clutch cable adjuster until the freeplay is 0.4 - 0.8 in (10 - 20 mm).
3. Tighten the upper lock nut and check the freeplay again.



### Lower Adjustment

If the upper clutch cable adjuster is threaded out near its limit, or the correct freeplay cannot be obtained, attempt adjustment with the lower clutch cable adjusting nut.