


Brakes

Brake Shoe Wear

The rear brake is equipped with external brake wear indicator that let you check brake wear without disassembly. Application of the brake control (pedal) causes the brake arm to move toward a reference mark on the brake panel.

RIGHT REAR



(1) arrow
(2) brake arm

(3) reference mark
(4) brake panel

1. Place your motorcycle on its side stand.
2. Apply the brake control (pedal) and check the movement of the arrow (1) on the brake arm (2). Replace the brake shoes if the arrow aligns with the reference mark (3) on the brake panel (4) upon full application of the brake. If replacement is necessary, see your dealer.