


## Additional Maintenance Procedures

Refer to *Safety Precautions* on page 25.

### Steering Head Bearing Inspection

1. With your CRF on a box or optional workstand (front wheel elevated), turn the handlebar to the right and left to check for roughness in the steering head bearings.




2. Stand in front of your CRF, grab the fork (at the axle), look at the steering head, and push the fork in and out (toward the engine) to check for play in the steering head bearings. If any roughness or play is felt, but you do not see any movement in the steering head, the fork bushings may be worn. Refer to the Honda Shop Manual for replacement or adjustment procedures, or see your Honda dealer.



### Handlebar Inspection

1. Remove the handlebar pad.
2. Check the handlebar (1) for bends or cracks.
3. Check that the handlebar has not moved from its proper position (by inspecting the paint mark).
4. Check the torque of the handlebar upper holder bolts (2):  
22 N·m (2.2 kgf·m, 16 lbf·ft)  
Tighten the front bolts first.



(1) handlebar

(2) handlebar upper holder bolts

### Control Cables

Periodically, disconnect the throttle, clutch and hot start cables at their upper ends. Thoroughly lubricate the cable pivot points with a commercially-available cable lubricant. If the clutch lever, hot start lever and throttle operation is not smooth, replace the cable. Be sure the throttle returns freely from fully open to fully closed automatically, in all steering positions.