


6. Disconnect the spark plug cap from the spark plug.
7. Clean any dirt from around the spark plug base.
8. Remove the spark plug using the spark plug wrench provided in the tool kit.



9. Inspect the electrodes and centre porcelain for deposits, erosion or carbon fouling.
 - If the erosion or deposit is heavy, replace the plug.
 - Clean a carbon or wet-fouled plug with a plug cleaner, otherwise use a wire brush.