

Basic Operation & Riding

This section gives basic riding instructions, including how to start and stop your engine, and how to use the throttle, clutch, and brakes. It also provides important information on riding with a passenger or cargo, and operating your cruise control.

To protect your new engine and enjoy optimum performance and service life, refer to Break-in Guidelines (page 260).

To protect the catalytic converters in your motorcycle's exhaust system, avoid extended idling and the use of leaded gasoline.

Safe Riding Precautions	70
Starting & Stopping the Engine	71
Preparation	71
Starting Procedure	72
Flooded Engine	72
Bank Angle Sensor Ignition Cut-off System	73
How to Stop the Engine	73
Shifting Gears	74
While You Are Riding	75
Riding in Reverse	76
Braking	78
Combined ABS	80
ABS Indicator Light	81
Tire Pressure Monitoring System (TPMS)	83
Low Tire Pressure Indicator	84
Tire Pressure Monitoring System (TPMS) Indicator	85
Changing a Tire with TPMS	86
Parking	87
Theft-prevention Tips	89
Riding with a Passenger or Cargo	90
Riding with Cruise Control	91
Cruise Control	91
To Set Cruise Control	92
To Change the Set Speed	92
To Cancel Cruise Control	93
Riding in Bad Weather	94