




S mode level selecting while in AT MODE



While in S mode, press and hold the D-S side of the N-D (1) switch.

- ▶ Close the throttle completely. Then select the desired level of the S mode.



-  Press and hold the D-S side of the N-D switch
-  Press the D-S side of the N-D switch

N-D switch



The selected level is maintained even when the ignition switch is turned to the OFF position, or transmission is switched to out of S mode.