


Checking the Final Drive Oil

1. Place your motorcycle on the side stand on a level surface.
2. Remove the oil fill hole cap.
3. Check the oil level. It should be flush with the lower edge of the oil fill hole.



Adding Final Drive Oil

If the final drive oil level is low, check for oil leaks. Add the recommended final drive oil (P. 44) until it reaches the lower edge of the opening.

1. Pour the final drive oil into the oil fill hole until it reaches the lower edge of the opening.
 - ▶ Do not over fill above the lower edge of oil fill hole.
 - ▶ Make sure no foreign objects enter the oil fill hole.
 - ▶ Wipe up any spills immediately.
2. Reinstall the oil fill hole cap and tighten.

Torque: 9 lbf·ft (12 N·m, 1.2 kgf·m).