

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
	I: (EVERY YEAR)		8-10
*	I: (EVERY YEAR)		36
	I	I	34
	I	I	27
*	I: (EVERY YEAR)		-
	I	I	26
*	A	A	38
*		C	39
	I	I	-
	I	I	15
*	A: (EVERY YEAR)		-