

TIRES

Proper air pressure will provide maximum stability, riding comfort and tire life.

Check tire pressure frequently and adjust if necessary.

NOTE: Check tire pressure when the tires are "cold", before you ride.

On/Off-road tires are standard on this model. Select the right replacement tires in accordance with the following specifications:

NEUMATICOS

Una presión de aire adecuada proporcionará la máxima estabilidad, comodidad en la conducción duración de los neumáticos.

Comprobar la presión de los neumáticos frecuentemente y ajustarla cuando ello sea necesario.

NOTA: Revise la presión del neumático cuando éste está todavía "frío" antes de comenzar la conducción.

Los neumáticos para carretera y todo terreno son estándar en este modelo. Elegir los neumáticos de repuesto apropiados de acuerdo a las especificaciones siguientes: