

Tires – Check the air pressure and tires for wear or damage. (See page 112.)

Battery electrolyte – Check the level and add if necessary. (See page 104.)

Throttle operation – Check the throttle operation, cable routing and free play. Correct or replace if necessary. (See page 78.)

Light and horn – Check that headlight, tail/stoplight, turn signals, indicators and horn function properly.

Llantas – Revise la presión del aire, estado de desgaste o daño de las llantas. (pág. 112)

Electrólito de la batería – Revise el nivel y agregue, si es necesario. (pág. 104)

Funcionamiento del acelerador – Revise el funcionamiento del acelerador, instalación de sus cables, y sus juegos libres. Corrija o reemplace, si es necesario. (pág. 78)

Luz y bocina – Revise un buen estado de funcionamiento del faro, luz trasera/de freno, luz de señales de direcciones, alumbrado de contadores y operación de la bocina.