

3. Reinstall the plug (4), making sure that the plain washer is in good condition.
4. Install the oil filter element and tighten the filter cover (6), making sure the O-rings are in good condition.
5. Fill with approx. 2.5 liters (2.6 U.S. qt., 2.2 Imp. qt.) of recommended grade oil. Start the engine and run for several minutes; then stop it and recheck the oil level. Add oil if necessary.

**CAUTION: Change the oil more frequently than recommended on page 127, depending upon the severity of dust conditions.**

- 
3. Remonte los tapone (4), asegurándose de que la randela plana se encuentre en buen estado.
  4. Instale el elemento del filtro de aceite y apriete la cubierta del filtro (6), asegurándose de que las juntas anulares estén en buen estado de montaje.
  5. Llene el cárter con 2,5 litros, aproximadamente, de aceite de la calidad recomendada. Arranque el motor y haga marchar por unos minutos; luego, párelo y revise el nivel de aceite otra vez. Agregue aceite, si es necesario.

**PRECAUCION: Cambie el aceite más frecuentemente que lo recomendado en la página 127, dependiendo de las condiciones de polvo en la zona de conducción.**