

Top Compartment

Use the ignition key to open the top compartment covers. The tool tray (1) is under the forward cover. The owner's manual and other documents should be stored in the plastic bag in this tray. When washing your motorcycle, be careful not to flood the compartment.

Seat

The seat can be set in three positions. To adjust, pull the seat lock (2) and move the seat. After adjustment make sure that seat is secure and your riding position is comfortable.



Compartimiento de arriba

Use la llave de contacto para abrir las cubiertas del compartimiento de arriba. La bandeja para herramientas (1) se encuentra debajo de la cubierta delantera. Guarde el manual de explicaciones y otros documentos en un saco de plástico en esta bandeja. Cuando lava la moto, preste atención de no inundar el compartimiento.

Asiento

El asiento puede ajustarse a tres posiciones. Para hacer el ajuste tirar hacia afuera del fiador de sujeción (2) y mover el asiento. Después del ajuste, asegúrese de que el asiento está firmemente fijado y su posición de conducción es confortable.

