

Ref. No.	Description	Function
6	Left turn signal indicator	Flashes when left turn signal operates.
7	Oil level warning light	<p>Light should come on for 5 seconds after turning the ignition switch on, then go out, except for occasional flickering near or at the lower oil level. If light comes on and does not go out, oil level is below normal operating range; there is about 0.4ℓ (0.42 US qt, 0.35 Imp. qt.) left in the engine oil tank. Refill the oil tank as soon as possible. If light does not come on, there is a fault in the oil level warning system.</p> <p>CAUTION: Running the engine with insufficient oil will cause serious engine damage.</p>

Nº de ref.	Description	Fonction
6	Témoin de clignotants gauche	Clignote lorsque le clignotant gauche fonctionne.
7	Témoin de niveau d'huile	<p>Le témoin de niveau d'huile doit rester allumé pendant 5 secondes après que le commutateur d'allumage est enclenché, puis s'éteindre après ce délai. Il clignote occasionnellement lorsque l'huile est proche du niveau minimum. Si le témoin s'allume et ne s'éteint pas, c'est le signe que le niveau d'huile se trouve en dessous de l'intervalle normal de fonctionnement. Il reste alors environ 0,4 litre dans le réservoir d'huile moteur. Dans ce cas, remplir le réservoir d'huile aussitôt que possible. Si le témoin ne s'allume pas, il y a une anomalie dans le circuit d'alerte de niveau d'huile.</p> <p>PRECAUTION: Si le moteur est utilisé avec une quantité d'huile insuffisante, il risque d'être sérieusement endommagé.</p>