

Installation:

1. Insert the front prong of the seat into the recess under the fuel tank rear mount.
2. Install the seat by pressing down on the rear of the seat until the seat latches engage.
3. Check that the seat is installed securely.

WARNING: Before installing the seat, make sure there are no rags or wastes on the frame. They may be burned when the engine becomes heated.

Repose:

1. Introduire la patte avant de la selle dans l'encastrement sous la monture arrière du réservoir d'essence.
2. Reposer la selle en enfonçant l'arrière de la selle jusqu'à ce que les loquets de la selle s'engagent.
3. S'assurer que la selle est bien posée.

ATTENTION:

Avant de reposer la selle, s'assurer qu'il n'y a pas de chiffons ou de restes sur le cadre. Ils risquent d'être brûlés lorsque le moteur devient chaud.