Instruments *(Continued)*

2 Changing of tachometer display mode:

You can change the display mode of the tachometer.

1. Press **SEL** button to switch the display mode of tachometer.
2. Press **SET** button. The currently selected display mode is set, and then the display moves to the ordinary display.

Conventional display

Shows the engine RPM on the tachometer bar segment.

Peak hold display

Shows the engine RPM on the tachometer bar segment and peak hold segment.

