Instruments *(Continued)*

2 Clock setting:

❶ Press the SEL ▲ (up) button or the SEL ▼ (down) button until the desired hour is displayed.

  u Press and hold the SEL ▲ (up) button or the SEL ▼ (down) button to advance the hour fast.

❷ Press the MODE button. The minute digits start flashing.

❸ Press the SEL ▲ (up) button or the SEL ▼ (down) button until the desired minute is displayed.

  u Press and hold the SEL ▲ (up) button or the SEL ▼ (down) button to advance the minute fast.

❹ Press the MODE button. The clock is set, and then the display moves to the backlight brightness adjustment.