Switch the Day Mode Display and Night Mode Display

(Models equipped with Navigation System)
The display automatically switches to the Day mode or Night mode in
accordance with the time. To switch the display manually, push and hold the
DIM button.
Refer to the Navigation System Manual for further information.

DIM button   DIM button