Maintenance Component Locations

———————➤ Indicates something visible.
- - - - - - - - - ➤ Indicates something concealed.

owner's manual
(page 91)

front hood
(page 92)

coolant
reserve tank
(page 114)

fuel fill cap
(page 96)

front differential oil fill cap
front differential oil drain bolt
(page 109, 110)