2 Clock setting:

! Press the SEL button until the desired hour is displayed.

   u When the 12-hour display is set, the AM/PM is displayed. The display changes from 11 to 12, it will switch at the same time.

   u Press and hold the SEL button to advance the hour fast.

! Press the SET button. The minute digits start flashing.

! Press the SEL button until the desired minute is displayed.

   u Press and hold the SEL button to advance the minute fast.

! Press the SET button. The clock is set, and the display moves to the backlight brightness H (high) adjustment.

3 Backlight brightness H (high) adjustment:

You can adjust the brightness to one of five levels.

! Press the SEL button. The brightness is switched.

! Press the SET button. The brightness H (high) is set, and the display moves to the backlight brightness L (low) adjustment.