

CONTENTS

EQUIPMENT AND CONTROLS	10
FUEL AND OIL	36
PRE-RIDING INSPECTION	44
STARTING ENGINE	48
BREAK-IN PROCEDURE	52
RIDING THE MOTORCYCLE	54
MAINTENANCE	58
Engine Oil	58
Oil Filter Maintenance	64
Spark Plug	66
Valve Tappet Adjustment	68
Contact Breaker Points	72
Ignition Timing	74
Air Cleaner Maintenance	76
Throttle Cable Adjustment	80
Carburetor Adjustment	82
Clutch Adjustment	86
Drive Chain Adjustment	90
Drive Chain Lubrication	94
Front Brake Adjustment	96
Rear Brake Adjustment	98
Brake Wear Indicators	100

INDICE

EQUIPOS Y CONTROLES	11
COMBUSTIBLE Y ACEITE	36
INSPECTION ANTES DE PUESTA EN MARCHA	44
ARRANQUE DLE MOTOR	48
RODAJE	48
CONDUCCION	52
MANTENIMIENTO	54
Aceite para motor	58
Mantenimiento del filtro de aceite	58
Bujías	64
Ajuste de las válvulas	66
Puntos de interruptor de contactos	68
Ajuste del tiempo de encendido	72
Mantenimiento del filtro de aire	74
Ajuste del cable del acelerador	76
Ajuste del carburador	80
Ajuste del embrague	82
Ajuste de la cadena de transmisión	86
Lubricación de la cadena de transmisión	90
Ajuste del freno delantero	94
Ajuste del freno trasero	96
Indicador de desgaste del freno	98
	100