	ITEM \ FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	× 1,000 km	1	6	12	18	24	30	36	Refer to Page
			× 1,000 mi	0.6	4	8	12	16	20	24	
			MONTH		6	12	18	24	30	36	
				ODOMETER READING [NOTE (1)]							
	DRIVE CHAIN			I, L EVERY 1,000 km (600 mi)							104
	DRIVE CHAIN SLIDER					I		I		I	110
	BRAKE FLUID	NOTE (3)			I	I	R	I	I	R	35
	BRAKE PAD WEAR				I	I	I	I	I	I	118
	BRAKE SYSTEM			I		I		I		I	35
*	BRAKE LIGHT SWITCH					I		I		I	—
*	HEADLIGHT AIM					I		I		I	—
	CLUTCH SYSTEM			I	I	I	I	I	I	I	38
**	EXHAUST VALVE CONTROL CABLE			EVERY 24,000 km (16,000 mi) I							—
	SIDE STAND					I		I		I	112
*	SUSPENSION					I		I		I	111
*	NUTS, BOLTS, FASTENERS			I		I		I		I	—
**	WHEELS/TYRES					I		I		I	—
**	STEERING HEAD BEARINGS			I		I		I		I	—