03/05/20 10:03:32 31KCY680_059

Maintenance Schedule

Items	Frequency	Whichever Comes First ⇨		Initial Maint.	Regular Maint. Interval				Refer to page:
			mi	100	600	1,200	1,800	2,400	
			km	150	1,000	2,000	3,000	4,000	
		Note	Month	1	6	12	18	24	
NON−EMISSION RELATED ITEMS	Drive Chain	Note 1		I, L	I, L: every 300 mi (500 km) or 3 months				123
	Drive Chain Slider				I	I	I	I	124
	Brake Fluid	Note 3			I	I	I	I	108
	Brake Pad Wear				I	I	I	I	110
	Brake System			I	I	I	I	I	107
*	Headlight Aim					I		I	131
	Clutch System			I	I	I	I	I	80
	Side Stand					I		I	122
*	Suspension					I		I	88
*	Spark Arrester				C: every 1,000 mi (1,600 km) or every 100 operating hours				86
*	Nuts, Bolts, Fasteners			I		I		I	—
* *	Wheels/Tires			I	I	I	I	I	112, 118
* *	Steering Head Bearings			I		I		I	—

* Should be serviced by your Honda dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 172).

**In the interest of safety, we recommend these items be serviced only by your Honda dealer.