Troubleshooting

Engine Will Not Start ..... P. 150
Overheating (Segment H flashes in coolant temperature gauge) ..... P. 151
Warning Indicators On or Flashing ..... P. 152
- Low Oil Pressure Indicator ..... P. 152
- PGM-FI (Programmed Fuel Injection) Malfunction Indicator Lamp (MIL) ..... P. 152
- ABS (Anti-lock Brake System) Indicator ..... P. 153
- Torque Control Indicator ..... P. 154

If the "–" Indicator is Blinking in the Gear Position Window While Riding ..... P. 155
Other Warning Indications ..... P. 156
- Fuel Gauge Failure Indication ..... P. 156
- Coolant Temperature Gauge Failure Indication ..... P. 157
- Handle Grip Heater Failure Indication ..... P. 157

Tire Puncture ..... P. 158
Electrical Trouble ..... P. 167
- Battery Goes Dead ..... P. 167
- Burned-out Light Bulb ..... P. 167
- Blown Fuse ..... P. 170