

### Installation:

1. Position the front wheel between the fork legs and insert the axle from the left side through the left fork leg and wheel hub.  
To prevent any damage to the brake pads fit the brake disk very carefully between the pads.  
Take care not to damage the ABS sensor (if present) on the right caliper. (CBF500A)
2. Tighten the axle bolt(2) to the specified torque. Front axle torque:  
59 N•m (6,0 kgf•m)
3. Tighten the axle pinch bolts (1) on the fork legs to the specified torque:  
22 N•m (2,25 kgf•m)
4. Operate the front brake and pump the fork several times.