



If You Have a Flat Tire

Installation

1. Position the wheel.
2. Position the wheel nuts so that the tapered sides face the wheel rim.
3. Hand-tighten the wheel nuts on the wheel, then lower the Honda MUV to the ground before tightening the nuts in a crisscross (rather than circular) pattern to the specified torque:
79.7 lbf-ft (108 N-m , 11.0 kgf-m)

If a torque wrench was not used for installation, see your Honda dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capability.