

7. After the oil has drained, install the drain bolt with new sealing washer and tighten to the specified torque:
22 lbf·ft (30 N·m, 3.1 kgf·m)
8. Pour the recommended oil into the crankcase, approximately:
1.1 US qt (1.0 ℓ)
9. Install the oil fill cap/dipstick securely.
10. Start the engine and let it idle for 3-5 minutes. Stop the engine. Wait 2-3 minutes.

11. With the motorcycle held upright on level ground, check the oil level.
If needed, add oil (page 65) until it reaches the upper level mark. (Do not overfill.)
12. Check for oil leaks.
13. Install the engine guard.