

5. Remove the rear axle shaft (10), drive chain adjusters (11) and side collars, then remove the drive chain (12) from the driven sprocket by pushing the rear wheel forward.
6. Remove the rear wheel from the motorcycle.