

WARNING


- * Always turn the engine off before performing any maintenance operations unless otherwise stated.*
- * To maintain the safety and reliability of your HONDA ATC do not modify it and use only new genuine HONDA parts or their equivalent when servicing or repairing.*
The use of replacement parts which are not of equivalent quality may impair the operation of your ATC.

TOOL KIT

The tool kit is stored in the compartment (1) shown below. The tools provided are sufficient to perform routine maintenance and simple repairs. Any extensive work requiring additional tools should be performed by an authorized Honda motorcycle dealer.

Listed below are the items included in the tool kit:

- 8x12mm open end wrench
- 10x14mm open end wrench
- Spark plug wrench
- Pliers ● Screwdriver blade ● Screwdriver handle
- 17mm socket wrench ● Socket wrench handle
- Tool bag



(1) Tool kit compartment