

DESCRIPTION

PARTS LOCATION

- (1) Front brake lever
- (2) Throttle lever
- (3) Neutral indicator lamp
- (4) Rear brake lever/
parking brake
- (5) Fuel tank cap
- (6) Fuel valve
- (7) Recoil starter
- (8) Gearshift pedal
- (9) Neutral indicator
- (10) Posi-torque speed range
selector

