

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
	FUEL LINE	I: (EVERY YEAR)		33
*	FUEL STRAINER	C: (EVERY YEAR)		33
	THROTTLE OPERATION	I	I	45
	DRIVE CHAIN	I	I	46
*	BRAKE SHOES	I: (EVERY YEAR)		42
	BRAKE CONTROL LINKAGE	I	I	42
*	CLUTCH	A	A	41
*	SPARK ARRESTER		C	48
	ALL NUTS, BOLTS, FASTENERS	I	I	—
	LIGHTING EQUIPMENT	I	I	—
	TIRES	I	I	13
*	STEERING HEAD BEARING	A: (EVERY YEAR)		—