

PRE-RIDE INSPECTION

WARNING

** If the Pre-ride Inspection is not performed, serious damage or an accident may result.*

Inspect your ATC every day before you ride it.

The items listed here will only take a few minutes to check, and in the long run they can save time expense and possibly your life.

1. Fuel lever-fill the fuel tank when necessary (page 11). Check for leaks.
2. Brakes-check operation and fluid level (page 49–52).
3. Tires-check condition and pressure (page 14).
4. Drive chain-check condition (particularly the master link) and slack (page 54). If necessary, adjust and lubricate (page 54).
5. Throttle-check for smooth opening and closing in all steering positions (page 53).
6. Headlight switch-check for proper function (page 6).
7. Engine stop switch – check for proper function (page 6).
8. Nuts, bolts, fasteners-check wheels to see that axle nuts are tightened and secured by cotter pins.

Check the security of all other nuts, bolts and fasteners.

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.