

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust		EVERY	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to pages
*	VALVE CLEARANCE		I	I	52-53
	ENGINE OIL		R	R	22-23
	ENGINE OIL FILTER		R	R	45
*	CARBURETOR IDLE SPEED		I	I	47
	FINAL DRIVE OIL	YEAR: I 2 YEARS: R			59
*	BRAKE SHOE WEAR	YEAR: I NOTE 2			55, 57
*	REVERSE LOCK SYSTEM		I	I	-
	BRAKE SYSTEM		I	I	55-57
	ENGINE UNDER GUARD AND SKID PLATE			I	60
*	CLUTCH SYSTEM		I	I	54
*	SUSPENSION			I	-
*	NUT, BOLT, FASTENER		I	I	-
**	WHEELS		I	I	-
**	STEERING HEAD BEARING	YEAR: I			-