

CONTENTS

	Page		Page
ATC SAFETY	1	Spark Plug	46
DESCRIPTION	4	Air Cleaner	47
Parts Location	4	Clutch	48
Serial Numbers	6	Brakes	50
Parts Function	7	Throttle Cable	54
Fuel	11	Drive Chain	55
Transmission Oil	14	Spark Arrester	57
Coolant	16	STORAGE	58
Tires	18	TRANSPORTING	59
Front Suspension	20	NOISE EMISSION CONTROL	63
Rear Suspension	21	SPECIFICATIONS	64
OPERATION	25	WIRING DIAGRAM	65
Pre-ride Inspection	25	PERIODIC REPLACEMENT PARTS	66
Starting the Engine	26	OPTIONAL PARTS	67
Break-in	28	WARRANTY SERVICE	72
Riding	29		
Parking	37		
MAINTENANCE	38		
Maintenance Schedule	38		
Tool Kit	41		
Fuel Filter	42		
Carburetor	43		