

Valve Tappet Adjustment	27	Turning Maneuvers	41
Contact Breaker Point Gap and Ignition Timing Adjustment	29	Skidding	43
Spark Plug Replacement and Adjustment	31	Climbing Hills	45
Air Filter Maintenance	32	Descending Hills	48
Throttle Cable Inspection and Adjustment	34	Traversing Slopes	49
Carburetor Adjustment	35	Tire Care	50
Fuel Filter Maintenance	36	Transporting the ATC	51
Cam Chain Adjustment.....	37	Removing The Rear Wheels	53
Clutch Adjustment	38	Installing The Rear Wheels	53
RIDING THE HONDA ATC	39	Removing The Front Wheel	54
Safety Precautions	40	Installing The Front Wheel	54
		SPECIFICATIONS	55
		WIRING DIAGRAM	57