

## SPEED LIMITER


The speed limiter is a screw installed in the throttle control case. It limits maximum throttle travel and thus limits top speed to about 25 Km/h. (16 mph). This limiter is especially applicable to beginning riders. After the rider becomes proficient, the speed limiter can be removed by loosening the lock nut ① and removing the speed limiter screw ②. After removing the speed limiter, plug the hole with the screw enclosed with ATC 70.

### WARNING

Failure to plug the hole after removing the speed limiter screw will allow dirt to enter, and may cause the throttle to stick open.

### CAUTION:

*To prevent rapid clutch wear, do not operate below 20 km/h (13 mph) in 4-th gear.*



① Lock nut    ② Speed limiter screw