

## TIRES

Although the tires are designed specifically for off-road use, they are not immune to punctures. Always select your driving area with care.

### WARNING

The ATC70 is not designed to be ridden on paved surfaces. Handling and control will be severely affected.

Tires should be inflated to the recommended pressure.

### NOTE:

Tire pressure should be checked when the tires are "cold," before you ride.

If no air pressure gauge is available to accurately measure the recommended pressure, this value can be estimated by measuring the circumference of the tires with a measuring tape. When inflated to the recommended pressure, the maximum tire circumference measured over the

tread ribs will be approximately the standard tire circumference. The relationship between tire pressure and actual circumference varies slightly with factors of wear and stretching that occur through use.

### NOTE:

The circumference of the tires should be measured with the tires raised off the ground.

**Recommended Pressure: 2.2 psi**  
(15 kPa, 0.15 kg/cm<sup>2</sup>)

**Max Pressure: 2.5 psi**  
(18 kPa, 0.18 kg/cm<sup>2</sup>)

**Min Pressure: 1.7 psi**  
(12 kPa, 0.12 kg/cm<sup>2</sup>)

**Standard Tire Circumference at recommended air pressure: 1,290 mm (50.7 in)**

### Tire Size

16 x 8.0-7

